





A PK-PRO 2 Net





B PK-PRO CARRY BAG

Unfold PK-Pro Net in front of the goal. Make sure bottom grommets are even with the uprights on the goal.




Connect lowest net section which is the widest part of the PK-Pro 2 net. Wrap velcro straps to lower goal pole.






Connect the right side velcro straps to post and crossbar.



Connect the left side velcro straps to post and crossbar.





Finally tweak shape by moving and adjusting Bungee Chords, then start your training.

